



## Premium force measuring instrument with graphic-assisted display

### Features

- **Turnable display** with backlight
- **Peak-Hold function** to capture peaks (measurement result will be “frozen” for a short time) or **Track function** mode for a continuous measurement indication (period of time approx. 10 s)
- **Metal housing** for durable usage in harsh environmental conditions
- Can be mounted on all SAUTER test stands
- **Capacity display:** A bar lights up to show how much of the measuring range is still available
- **Limit value function**, programming of Max./Min., in pull and push direction, with output of acoustic and optical signal. Ideal mode for efficient and accurate testing of standard parts
- **Internal memory** for up to 500 measurements
- **Continuous analogue output:** Linear voltage signal in relation to the load (-2 to +2V)
- **1** Delivered in a hard carrying case

- **2** SAUTER FL 2K: with external sensor, Tension loops and pressure plates are included in delivery
- **3** Standard attachments: as shown besides (not for FL 2K)
- Selectable measuring units: N, KN, kg, oz, lbf

### Technical data

- Internal measuring frequency: 1000 Hz
- Precision: 0,2 % of [Max]
- Overload protection: 120 % of [Max]
- Dimensions W×D×H 175×75×30 mm
- Thread: M6
- Dimensions load cell W×D×H 51×76,2×19 mm
- Thread: M12
- Rechargeable battery pack integrated, standard, operating time up to 10 h without backlight, charging time approx. 8 h
- Net weight approx. 0,5 kg

### Accessories

- **Plug-In for data transfer of measuring data** from the measuring instrument and transfer to a PC, e.g. in Microsoft Excel®, SAUTER AFI-1.0
- **Force-time data transfer software** for graphical representation on the PC and data transfer to Microsoft Excel®, SAUTER AFH FAST
- **Force-displacement data transfer software** with graphic display of the measurement process, SAUTER AFH FD
- **USB cable**, SAUTER FL-A01
- **RS-232 adapter cable**, SAUTER FL-A04
- **Thermal printer**, KERN YKB-01N
- **Statistics thermal printer**, KERN YKS-01
- **Label printer**, KERN YKE-01
- For information on holders to hold objects in place as well as other accessories, please see page 24 onwards or [www.sauter.eu](http://www.sauter.eu)

#### STANDARD



































#### OPTION



s. p. 65

Model	Measuring range	Readout	Option DAKKS calibration certificate			
			Tensile force		Compressive force	
			DAKKS KERN		DAKKS KERN	DAKKS KERN
SAUTER	[Max] N	[d] N				
FL 5	5	0,002	963-161		963-261	963-361
FL 10	10	0,005	963-161		963-261	963-361
FL 20	25	0,01	963-161		963-261	963-361
FL 50	50	0,02	963-161		963-261	963-361
FL 100	100	0,05	963-161		963-261	963-361
FL 200	250	0,1	963-161		963-261	963-361
FL 500	500	0,2	963-161		963-261	963-361
FL 1K	1000	0,5	963-162		963-262	963-362
FL 2K	2500	1	963-162		963-262	963-362

	<b>Adjusting program (CAL):</b> For quick setting of the balance's accuracy. External adjusting weight required.		<b>Control outputs (optocoupler, digital I/O):</b> to connect relays, signal lamps, valves, etc.		<b>Mains adapter:</b> 230V/50Hz in standard version for EU. On request GB, AUS or USA version available.
	<b>Calibration block:</b> standard for adjusting or correcting the measuring device.		<b>Analogue interface:</b> to connect a suitable peripheral device for analogue processing of the measurements.		<b>Power supply:</b> Integrated, 230V/50Hz in EU. More standards e.g. GB, AUS or USA on request.
	<b>Peak hold function:</b> capturing a peak value within a measuring process.		<b>Statistics:</b> using the saved values, the device calculates statistical data, such as average value, standard deviation etc.		<b>Motorised drive:</b> The mechanical movement is carried out by a electric motor.
	<b>Scan mode:</b> continuous capture and display of measurements.		<b>PC Software:</b> to transfer the measurements from the device to a PC.		<b>Motorised drive:</b> The mechanical movement is carried out by a synchronous motor (stepper).
	<b>Push and Pull:</b> the measuring device can capture tension and compression forces.		<b>Printer:</b> a printer can be connected to the device to print out the measurements.		<b>Fast-Move:</b> the total length of travel can be covered by a single lever movement.
	<b>Length measurement:</b> captures the geometric dimensions of a test object or the movement during a test process.		<b>GLP/ISO record keeping:</b> of measurements with date, time and serial number. Only with SAUTER printers.		<b>DAkkS calibration possible:</b> The time required for DAkkS calibration is shown in days in the pictogram.
	<b>Focus function:</b> increases the measuring accuracy of a device within a defined measuring range.		<b>Measuring units:</b> Weighing units can be switched to e.g. non-metric at the touch of a key. Please refer to website for more details.		<b>Factory calibration:</b> The time required for factory calibration is specified in the pictogram.
	<b>Internal memory:</b> to save measurements in the device memory.		<b>Measuring with tolerance range:</b> Upper and lower limiting can be programmed individually, e.g. for sorting and dosing.		<b>Package shipment:</b> The time required for internal shipping preparations is shown in days in the pictogram.
	<b>Data interface RS-232:</b> bidirectional, for connection of printer and PC.		<b>ZERO:</b> Resets the display to "0".		<b>Pallet shipment:</b> The time required for internal shipping preparations is shown in days in the pictogram.
	<b>Data interface USB:</b> To connect the balance to a printer, PC or other peripheral devices.		<b>Battery operation:</b> Ready for battery operation. The battery type is specified for each device.		<b>Warranty:</b> The warranty period is shown in the pictogram.
	<b>Data interface Infrared:</b> To transfer data from the balance to a printer, PC or other peripheral devices.		<b>Rechargeable battery pack:</b> rechargeable set.		

Your SAUTER specialist dealer: