

# CA 8345 Class A power quality analyser





IP 54

#### The Qualistar moves up a grade

- Voltage quality diagnostics
- Full compliance with IEC 61000-4-30 Class A
- Highly communicating instrument
- Qualistar range of easy-to-use products



#### Recording

Hundreds of parameters stored in memory every 10/12 periods.

#### Alarms

The parameters are monitored within configurable limits.

#### Transients

Fast events are captured and their characteristics are stored in memory.

#### TrueInrush

Studying loads during startup is now much simpler.







# Power and energy quality analyser

Intended for inspection and maintenance teams on industrial or tertiary installations , the Qualistars give you a snapshot of the main electrical network quality features.

Comfortable to handle and equipped with an intuitive GUI, these analysers offer high measurement accuracy. They also feature numerous calculated values and several processing functions.



#### **Functions & Measurements**



#### General

- · Portable energy quality anaylser
- Instrument compliant with IEC 61000-4-30 edition 3.0 Class A for all functions
- Measurements on all installation types: three-phase, Aron connection, etc.
- Electrical network monitoring with setting of alarms
- IP54 casing 55 mm thick with stand
- IEC 61010 CAT IV 1000 V
- · Parameterization with software for EN 50160 reports



- All DC components taken into account
- · Harmonics (amplitude and phase shift) from DC to the 63rd order
- · Inter-harmonic subgroups from 0 to the 62nd order
- 2 carrier current frequencies monitored
- Measurement of P, N, Q<sub>1</sub>, S and D power values (total and per phase)
- Measurement of energy values (total and per phase) with Energy valuation
- Internal GPS for precise UTC synchronization (NTP possible too)


## 💮 Communication

- USB 2.0 external flash drive supported (host devices)
- USB 2.0 connection with a PC
- Ethernet 100 Mbps communication
- Wi-Fi 802.11b/g communication
- Webserver for a remote user interface with Android, Microsoft and iOS applications
- Backup and recording of screenshots (image and data)
- Recording and export to a PC
- · Software for real-time data recovery and communication with a PC



#### **Ergonomics**

- Wide 7-inch colour LCD touch screen (WVGA)
- · Real-time display of waveforms (4 voltage and 4 current)
- DC current sensor power supply
- 5 x 50 Hz/60 Hz AC/DC voltage inputs
- User-friendly, multlingual GUI
- Intuitive use
- User profiles
- Fully multi-task instrument
- · Automatic recognition of different current sensors
- Display of phasor diagrams
- Waveforms at 512 samples per cycle, with Min/Max 2.5µs
- Real-time waveforms displayed from 1 cycle to 10/12 cycles



- Calculation of K factor & FHL
- Calculation of distorting voltages and currents
- Calculation of Displacement Power Factor (DPF) and Power Factor (PF)
- Calculation of Pst & Plt flicker and the sliding Pst
- Calculation of unbalance (current and voltage)
- Waveform Inrush with a duration of 10 minutes
- · RMS and Peak Inrush for up to 30 minutes
- Capture of hundreds of 2.5 µs transients
- · Capture shockwaves up to 12kV with a resoluton of 500ns
- Recording of trends
- Trend recording period from 200 ms to 2 hrs

# Standard verification campaigns


#### IEC 61000-4-30

#### Definition of the measurement methods

The International Electrotechnical Commission (IEC) has drawn up the IEC 61000-4-30 standard. This standard defines:

- the methods for measuring the quality parameters for the supply of power to electrical power networks
- in the form of alternating current at a stated fundamental frequency
- and how to interpret the results.


The measurement parameters are described for each applicable parameter in terms which provide reliable, repeatable results, however the method is implemented.



## IEC 61000-4-7

#### Harmonics and interharmonics

The IEC 61000-4-7 standard defines the measurement methods for voltage quality analysers so that they remain compliant with the emission levels stipulated in certain standards (e.g. the harmonic current limits specified by IEC 61000-3-2) and for the measurement of harmonic currents and voltages on the power networks themselves.




<b>a</b> C	∖?∣	ð 🕨	49	.98 Hz	3	1/05/21 12:33	84 <b>% m</b>
	(1)	2		3		N	
RMS	226.6 V~	220.8	٧~	225.0	V~	4.785 V~	
DC	+ 0.140 V=	+ 0.212	V=	+ 0.154	V=	-0.210 V=	
THD	2.6 %f	5.4	%f	2.6	%f		30
THD	2.6 %r	5.4	%г	2.6	%г	4.4 %r	<mark>4∨</mark> 48
CF	1.382	1.414		1.445		1.617	4A L1 L2 L3
Pinst	0.012	0.016		0.013			L3 N
Pst	0.116	0.130		0.123			•
Pit	0.108	0.117		0.111			
RMS	THD	CF	1			Ś	

#### EN 50160

#### Homogeneous tolerances

The EN 50160 standard characterizes the quality of the voltage supplied. It presents the different types of disturbances which may affect the voltage on a network. It lists the parameters to be monitored and defines how long the parameters should be monitored for.

With the PAT3 software, the Monitoring mode can be used to set up a simplified configuration of all the limits to be monitored and the parameters to be recorded.



#### IEC 61000-4-15

#### Short or long-term flicker


This is caused by mains voltage modulation. When it affects lighting, it gives an impression of unstable vision due to a light stimulus whose luminance or spectral distribution fluctuates over time.

There are 2 parameters calculated from the mains voltage.

- +  $P_{\rm st}$  which is a short-term assessment based on a 10-minute observation period
- $P_{\rm lt}$  which is a long-term assessment, usually over a period of 2 hours

## Viewing the signal and its components


The CA 8345 is an easy-to-use analytical tool. After connection, the CA 8345 immediately and totally automatically displays the voltages up to 1,000 V AC and DC and the currents, thanks to a function which automatically recognizes the sensor connected. A large number of sensors are compatible with the Qualistar range.




The Waveform mode automatically provides an oscillogram showing the voltage and/or current waveforms.

w 🖌	? ()	50.01 Hz	31/05/21 12:37	84 <b>% m</b>
	0	2	3	
P (W)	+ 4.414 k	+ 4.338 k	+ 4.422 k	▲ 3L
Q <sub>f</sub> (var)	-2.004 k	+ 0.245 k	+0.067 k	L1 L2 L3 Σ
D (var)	+0.120 k	+ 0.101 k	+0.039 k	
N (var)	+ 2.008 k	+ 0.265 k	+ 0.077 k	V
S (VA)	4.849 k	4.346 k	4.423 k	
W P	PF			

The CA8345 can be used to monitor all the power values (P, Q, D, etc.) in real time over periods of varying durations. Measurement and analysis of all the power values measured enables you to perform a full power survey in compliance with the standards.



It is very simple to measure harmonics and interharmonics with the CA 8345, which is very easy to use as an analytical tool.



The phase relation between the voltages and currents is displayed with a vectorial diagram. The vectorial representation allows you to confirm that the instrument is connected to the mains.

#### S 0. ? 01/07/21 09:27 892 8 Q; ? (0) 01/07/21 09:29 842 . ¢, ? © 898 1 ിരി 01/07/21 09:30 JOP12 JOP12 JOP12 O, SETUP 30 DISTRIBUTION SYSTEM E VOLTAGE RATIOS V1 + V2 + V3 + VN Trend mode Δ Alarm mode atio set-un Transient mode n (≡√) Monitoring mode 0 1.0k / 1000.0 3V V1V2 V2V3 V3V1 2 1.0k / 1000.0 Inrush mode **\*\*** Wh Energy mode ٦F 1.0k / 1000.0 Distribution System 30 Sensors / Ratio V ation methods X= 1.0k / 1000.0 0.

# With a simplified configuration

# Standard verification campaigns




#### **Energy valuation**

The Qualistar Class A offers users all the measurements required to successfully implement energy efficiency projects and monitor electricity distribution.

🐃 🤉 🤉 🎯 🚥	01/07/21 09:36 🛱 🖓 🏔 🎟
B ENERGY SPECIFIC TARIFFS	JOP12
Enabled	
Days	
Start	21h
Duration	3h
Tariff (kWh <sup>-1</sup> )	0.1200
1/8	
(O) 🔳 🗧 🖻	

🖌 Wh	2	0	50.0	)2 Hz	31/05/2	21 13:47	09 <b>8 H</b>
26/05/21	07:44	© 31/05/21	13:47				
		0 r		2 💌		<b>(3</b> P	
E <sub>P</sub> (€)		97.02		102.15		102.03	
E <sub>01</sub> (€)	¢	3.45	¢	5.78	ē	1.71	3L 12 13 13
	÷	42.85	÷	0.00	÷	0.00	12
E₀ (€)		4.17		1.91		0.81	Σ
E <sub>N</sub> (€)		47.39		6.13		1.85	
E <sub>3</sub> (€)		105.37		102.22		102.04	
0,		2-1	Wh	(())		-	F



#### **Shockwaves**


Usually caused by lightning, shockwaves are spectacular instantaneous electrical voltage surges. They also propagate in the digital network. The Qualistar Class A can withstand shockwaves up to 12 kV which are sampled every 500 ns.



#### **Carrier currents**

In the harmonic analysis function, there is also a mode for monitoring carrier currents. After defining their frequency in the instrument, the command signals will then be measured.

🗁 ALAF	RMS LIST	г				
17/06/21	12:24	L1	VMSV1	3.626 V	1s00	
		L1	VMSV1	3.610 V	1s00	
		L1	VMSV2	1.170 V	0s20	
		L1	VMSV1	3.460 V	0s80	L
		L1	VMSV2	1.212 V	0s20	L.
		L1	VMSV1	3.634 V	1s00	
		L1	VMSV1	3.460 V	1s00	Ē
		L1	VMSV2	1.167 V	0s20	
		L1	VMSV1	3.498 V	0s80	
3/51						



#### Interharmonics

electrical network.

The Qualistar Class A models can be used to measure and

display the interharmonics, as requested in IEC 61000-4-7,

for very precise analysis of all the disturbances on an

Lillium.


# Monitoring



#### Trend

The trend graph shows the variations of the parameters measured over time every 200ms.

*	<b>\$</b> ?	٥			13/04/21	11:09 🥥	09 <b>8 H</b>
10-	TENDENZ-	NODUS				USE	R1 💄
URMS			$\Box U_{PK}.$	□u⇔	Unior	Uner	Dug
V <sub>RMS</sub>	Vpc	$\checkmark V_{PK*}$	$\checkmark V_{\rm PK}$	VCF	VTHOF	<b>V</b> THDR	□vd
		APK+	APK.	Acr	ATHOP	ATHOR	Ad
ПР	Poc	<b>_</b> Q <sub>1</sub>		ΠN	□s	Pinst	□KF
PF	🖌 cos φ	🗌 tan φ		√Hz		Pst	FHL
<b>U</b> <sub>2</sub>	$\Box a_2$	$\Box u_0$	$\Box a_0$			DP <sub>8</sub>	FK
			1/3		1/4		
Þ		Ð	B	LO.	10-		



*	Ċ,	? 0		_			01/07/21	09:58 전 🖓 🛎 🎟	*	<u>)</u>	0		01/07/
Δ	ALAR	MODE		_				JOP12		LARMS LIS	т		
								×	19/05/21	17:02	L1	URMS	232.5 V
<b>V</b> 01	Ueus	10/12c	3L	<	300 V	1%	0s				L1	URMS	292.3 V
							**				L1	URMS	204.7 V
<b>V</b> 02	P	200ms	3L	>	4000 W	1%	0s				L2	URMS	254.7 V
03	Vens	%c	3L	<	215 V	1%	0s				L3	URMS	211.2 V
03	V RMS	726	JL.	`	215 V	179	US		20/05/21	16:44	L1	URMS	V 000.0
<b>V</b> 04	A <sub>ra/s</sub>	10/12c	3L	>	336 A	1%	5s				L2	URMS	0.156 V
05	VTHOF	10/12c	3L	>	8 %f	1%	0s				L3	URMS	0.000 V
			1/8	3									
		<b>F</b> 5	1		6				5	B			

	ARMS LIST	r				
19/05/21	17:02	L1	URMS	232.5 V	0s19	
		L1	URMS	292.3 V	0s19	- 4
		L1	URMS	204.7 V	0s19	
		∟2	URMS	254.7 V	0s19	
		L3	URMS	211.2 V	0s19	1
20/05/21	16:44	L1	URMS	0.000 V	1s80	
		∟2	URMS	0.156 V	1s80	2
		L3	URMS	0.000 V	1s80	

# **Alarms**


Alarms for parameterizing the threshold overruns to be monitored, which are then recorded and time-stamped with the duration and extreme values.

> Users can be informed directly by email when an alarm is triggered.




## **Transients**


Transients correspond to peaks in the voltage or current waveform. Shockwaves are extremely fast transients with even greater possible amplitude



#### **TrueInrush**


and currents).





# **Communication**

#### Software



The Power Analyzer Transfer software processes the measurements made with the Qualistar Class A.

- Configuration of the instrument: setup, recording, alarms
- Real-time display
- · Processing of all the recorded data
- · Transfer of screenshots and transients
- Data export into spreadsheet (Excel, .CSV)
- Data export in graphic form in Windows<sup>™</sup>

## Communication


In addition to using media such as SD cards and USB keys, it is possible to recover the measurements and communicate with the instrument remotely via USB, remote links, Wifi (direct or via server) or RJ45.

There is no limit to accessibility of the measurements.



#### The web server

The Qualistar Class A models are equipped with firmware for remote access. It can be controlled via VNC. which controls a remote machine while displaying its desktop. It can be activated from any browser (Chrome, Edge, Firefox, Qwant, etc.).



This means you can use any PC or smartphone, whether it is managed by iOS or Android.



#### **IRD Server**

All our IT networks are protected against external attack. Thanks to the provision of access to our IRD server, a single authorized IP output address allows you to transmit your measurements all over the world.

#### SCPI commands

With an integrated interfacing software layer, it is possible control your instrument via its own software application. SCPI commands are available for all the instrument's functions.

#### Data files in JSON format

Saved in JSON format, all the recordings are accessible and can be processed with a third-party and/or proprietary application.

# Applications



#### Tertiary and industrial

Today, electrical distribution networks are judged according to their ability to power loads causing disturbances and loads sensitive to disturbances. The latter may take multiple forms.

A voltage quality analyser can be used to detect and qualify each one: outage, dip, voltage swell, flicker, THD, voltage variations, etc.

#### Energy efficiency

For energy diagnostics on a site, a logger must be set up to record the electrical power and energy consumed. Once all the measurements have been taken, the billing data are compared with the actual measurements. The study determines whether corrective action needs to be taken. This action may take different forms: resizing of a transformer, implementation of filtering systems, replacement of faulty equipment, etc. This analysis helps you to act in the right place at the right time to provide the best solution.





# Electrical maintenance

The spread of electronic power supplies in industrial processes has led to an increase in harmonic disturbances on the electrical network which have a direct impact on the quality of the energy distributed. In the short or medium term, these disturbances may cause failures across all the electrical devices connected to the network in question. Harmonic currents have negative effects on nearly all the components in the electrical system, creating new dielectric, thermal and/or mechanical stresses.

# **Power and energy quality analysers**

#### **Current accessories**





#### **Essailec unit**

A cable with an ESSAILEC plug can be used to perform tests without disturbing or interrupting the power supply circuit on the meters and the protection relays installed in the secondary circuits of current or voltage transformers. The main advantage is that it speeds up and simplifies measurement while ensuring maximum user safety.



## **Reeling Box**

This practical magnetized reeling box equipped with the MultiFix system lets you adjust the lengths of your cables. The reeling box can be opened to install banana cables for voltage measurements or MiniFlex MA194 sensors for current measurements, as required. It also makes it simple to stow your cables.

## Shoulder bag

All-terrain bag with watertight base and shoulder strap (380 x 280 x 200 mm)



## with internal compartment

Compartmented internal bag for storage.



#### Magnetized mounting system



## **Power supply accessories**



The PA40W power supply with charger can power the instrument when it is used over long periods, so that you can work without draining the internal battery. It can also be used to recharge the battery.

#### PA32ER



The PA32ER power supply/charger can also be used to connected directly to a 1,000 AC or DC electrical network, between phases or phase-neutral with banana leads.

	PA40W-2	PA32ER
Rated voltage and overvoltage category	600 V CAT III	1000 V CAT IV
Input voltage	100 to 260 V	100 to 1,000 Vac / 150 to 1,000 Vdc
Input frequency	0 to 440Hz	DC, 40 to 70 Hz, 340 to 440Hz
Output power	40 W max	30 W max
Dimensions	160 x 80 x 57 mm	220 x 112 x 53 mm
Weight	460 g approx	900 g approx.









Li-ion battery charge support

	CA8345
Inputs	Voltage/current, isolated
Voltage	5 V to 1,000 Vac and Vdc
IEC 61000-4-30 (Ed 3)	Class A (Full)
Screen	7" colour LCD touch screen: 800 x 480 (WVGA)
Clock / GPS	Yes, built-in
Real-time mode	Yes
Sampling rate	Voltage 400 kSps / Current 200 kSps / Surge 2 MSps
Power mode	Yes
Energy mode	Yes
Unbalance mode	Composite
Harmonics mode	DC to 63rd order
Interharmonics mode	O to 62nd order
Trend recording	> 900 parameters
Alarm mode (types / number)	52 / 20,000
Carrier current detection mode	Yes
Inrush capture (number)	100
2.5 µs transients (number)	No maximum (SD card)
Shockwaves	Up to 12 kV sampled every 500ns
EN50160 monitoring mode	With PAT3 software
USB communication	Yes
SD card	Accessible, external
Ethernet	Yes
Wifi	Yes
Web server	Yes
USB key port (Type A)	Yes
Battery cartridge	Li-ion – 5800 Ah
IEC 61010 safety	CAT IV 1000V
Protection	IP54
Operating temperature	[+0 °C; +40 °C]
Environmental compliance	IEC 61557-12 & IEC 62586
Dimensions (H x L x D)	200x285x55 mm / 1.9 kg
Warranty	3 years

#### CA 8345 delivered with

- Safety datasheet
- 5 reeling boxes
- Shoulder bag
- Magnetic hookSD memory card

• Verification certificate

Removable wrist strap

- USB A/B cable 1.80 m longMultilingual Quick Start Guide
- Set of 5 banana leads and crocodile clips
- Set of identification inserts and rings

#### CA 8345 standard.....P01160657

• PA40W-2 mains power supply/charger

#### CA 8345-1000.....P01160658

• PA32ER mains power supply/charger

#### **Accessories / Replacement parts**

•	1000V STD PA32ER power supply	P01103076
•	PA40W-2 mains adapter	P01102155
•	C8 adapter	P01103077
•	Bag	P01298083
•	SD card	P01103078
•	Magnetized hook	P01103079
•	Wrist strap	HX0122
•	External battery charger support	P01102130
•	Li-ion battery	P01296047
•	C193 clamp	P01120323B
•	MN93 clamp	P01120425B
•	MN93A clamp	P01120434B
•	E27 clamp	P01120027
•	E3N/E27 adapter	P01102081
•	PAC93 clamp	P01120079B
•	J93 clamp	P01120110
•	In-vehicle charger	HX0061
•	AmpFlex® A193-450 mm clamp	P01120556B
•	AmpFlex® A193-800 mm clamp	P01120531B
•	MiniFlex MA194-250 mm clamp	P01120593
•	MiniFlex MA194-350 mm clamp	P01120592
•	MiniFlex MA194-1000 mm clamp	P01120594
•	5 A casing	P01101959
•	ESSAILEC casing	P01102131
•	PAC 93 mains adapter	P01101967
•	Reeling box	P01102149
•	Kit of banana leads with crocodile clips x5	P01295483
•	C7 mains power cable	P01295174



#### FRANCE

Chauvin Arnoux 12-16 rue Sarah Bernhardt 92600 Asnières-sur-Seine Tél : +33 1 44 85 44 85 Fax : +33 1 46 27 73 89 info@chauvin-arnoux.fr www.chauvin-arnoux.fr

#### UNITED KINGDOM

Chauvin Arnoux Ltd Unit 1 Nelson Ct, Flagship Sq, Shaw Cross Business Pk Dewsbury, West Yorkshire WF12 TTH Tel: +44 1924 460 494 Fax: +44 1924 455 328 info@chauvin-arnoux.co.ukr www.chauvin-arnoux.com MIDDLE EAST Chauvin Arnoux Middle East P.O. BOX 60-154

1241 2020 JAL EL DIB - LEBANON Tel: +961 1 890 425 Fax: +961 1 890 424 camie@chauvin-arnoux.com www.chauvin-arnoux.com